

**INSTALLER CHECK APPROPRIATE BOX AND PLACE LABEL ON OUTSIDE ACCESS PANEL**

<b>MODEL NO:</b> WKF1802B	<b>VOLTS:</b>	208-1P	230-1P
	<b>HTR WATTS:</b>	13500	16560
	<b>HTR AMPS:</b>	28.8-36.1	32.0-40.0

<b>EQUIPMENT MODEL NO</b>	<b>MCA</b>	<b>MOCP</b>	<b>MCA</b>	<b>MOCP</b>
FA4A,FB4A,FC4B 030-070	44.6-45.1	45-50	48.6-50.0	50-50
FA4B,FB4B,FC4C 030-070	42.8-45.1	45-50	46.8-50.0	50-50
FY4A,FA4C 030-070	42.5-45.1	45-50	46.5-50.0	50-50
FV4B,FE4A,FE5A 002-006	44.5-45.1	45-50	48.5-50.0	50-50
FK4C,FK4D 001-006	44.5-45.1	45-50	48.5-50.0	50-50
FX4C,FX4D,FC4D,FB4C 030-060	43.5-45.1	45-50	47.5-50.0	50-50
FX4A,FX4B 030-060	42.5-45.1	45-50	46.5-50.0	50-50
FH4 002-004	42.9-45.1	45-50	46.9-50.01	50-50
PF1MNA 030-061,PF4MNA 030-071	44.5-45.1	45-50	48.5-50.0	50-50

