

WARREN WKF CROSS REFERENCE

HEATERS FOR CARRIER/BRYANT/PAYNE	DATE: 6-24-14	FE4A/5A, 40FKA, FV4A/B/C 002-006; FA4A/B, FB4A/B/C, FC4B/C, FB5A 018-070; PF1MN, PF4MN 018-061; FZ4A 024-061 FC4D, FY4A, FY4B, FY5B, FA4C, FX4B/C 018-060; FH4A/B/C 001-004; FX4A 030-060; FK4C/D 001-006, FX4D 019-061
---	----------------------	--

WKF

WARREN MODEL#	SIMILAR TO CARRIER CORP. MODEL#	KW***	Voltage/ Phase	FITS	CIRCUIT PROTECTION
WKF0302	KFCEH0401N03	3	230/1	See Usage Chart	NONE
WKF0502	KFCEH0501N05	5	230/1	See Usage Chart	NONE
WKF0802	KFCEH0801N08	8	230/1	See Usage Chart	NONE
WKF0902C	KFCEH1401N09/ 2901N09	9	230/1 or 3	See Usage Chart	NONE
WKF1002	KFCEH0901N10	10	230/1	See Usage Chart	NONE
WKF1202^	N/A	12	230/1	See Usage Chart	NONE
WKF1202FS	N/A	12	230/1	See Usage Chart	FUSES
WKF1502^	KFCEH1501F15/ 3001F15	15	230/1	See Usage Chart	FUSES
WKF1502FS	N/A	15	230/1	See Usage Chart	FUSES
WKF2002^	KFCEH1801F20/ 3201F20	20	230/1	See Usage Chart	FUSES
WKF2002FS	N/A	20	230/1	See Usage Chart	FUSES
WKF0302B	N/A	3	230/1	See Usage Chart	CR BRKR
WKF0502B	KFCEH0601C05/ 2401C05	5	230/1	See Usage Chart	CR BRKR
WKF0802B	KFCEH1001C08/ 2501C08	8	230/1	See Usage Chart	CR BRKR
WKF1002B	KFCEH1101C10/ 2601C10	10	230/1	See Usage Chart	CR BRKR
WKF1202B^^	N/A	12	230/1	See Usage Chart	CR BRKR
WKF1202BS	N/A	12	230/1	See Usage Chart	CR BRKR
WKF1502B^^	KFCEH1701C15/ 3101C15	15	230/1	See Usage Chart	CR BRKR
WKF1502BS	N/A	15	230/1	See Usage Chart	CR BRKR
WKF1802B^^	N/A	18	230/1	See Usage Chart	CR BRKR
WKF2002B^^	KFCEH1901C20/ 3301C20	20	230/1	See Usage Chart	CR BRKR
WKF2002BS	N/A	20	230/1	See Usage Chart	CR BRKR
WKF0504	N/A	5	230/3	See Usage Chart	NONE

WARREN WKF CROSS REFERENCE

WARREN MODEL#	SIMILAR TO CARRIER CORP. MODEL#	KW	Voltage/Phase	FITS	CIRCUIT PROTECTION
WKF1004	N/A	10	230/3	See Usage Chart	NONE
WKF1504	KFCEH1601315	15	230/3	See Usage Chart	NONE
WKF1804	KFCEH2001318	18	230/3	See Usage Chart	NONE
WKF2404C	KFCEH2101F24/ 3401F24	24	230/3 or 1	See Usage Chart	FUSES
WKF3004C	KFCEH2201F30/ 3501F30	30	230/3 or 1	See Usage Chart	FUSES
WKF0504B	N/A	5	230/3	See Usage Chart	CR BRKR
WKF0804B	N/A	8	230/3	See Usage Chart	CR BRKR
WKF1004B	N/A	10	230/3	See Usage Chart	CR BRKR
WKF1504B	N/A	15	230/3	See Usage Chart	CR BRKR
WKF0305	N/A	3	480/3	See Usage Chart	NONE
WKF0505	N/A	5	480/3	See Usage Chart	NONE
WKF0805	N/A	8	480/3	See Usage Chart	NONE
WKF1005	N/A	10	480/3	See Usage Chart	NONE
WKF1505	N/A	15	480/3	See Usage Chart	NONE
WKF2005	N/A	20	480/3	See Usage Chart	NONE
WKF2505	N/A	25	480/3	See Usage Chart	NONE
WKF0305A	N/A	3	480/3	See Usage Chart	NONE
WKF0505A	N/A	5	480/3	See Usage Chart	NONE
WKF0805A	N/A	8	480/3	See Usage Chart	NONE
WKF1005A	N/A	10	480/3	See Usage Chart	NONE
WKF1505A	N/A	15	480/3	See Usage Chart	NONE
WKF2005A	N/A	20	480/3	See Usage Chart	NONE
WKF2505A	N/A	25	480/3	See Usage Chart	NONE

NOTES:

FOR REQUIREMENTS NOT LISTED CONSULT FACTORY

HEATERS ARE DUAL RATED 208/230 VOLT

480V heaters installed without autoformers in 240V 1Phase fan motor air handlers require two power sources or field supplied 480/240 step down transformers.

+ CONVERTIBLE TO SINGLE PHASE

* INCLUDES POWER FUSING

** CONVERTIBLE TO THREE PHASE

***NOMINAL KW

^ Single Point kit available for this model (WKFSPT)

^^ Single Point kit available for this model (WKFSPTB)

'A' = Autoformer for Single Point Connection Included 480 to 240 Volt, Internal Mount

'B' = HACR CIRCUIT BREAKER PROTECTION

'BS' = SINGLE POWER FEED AND HACR CIRCUIT BREAKER

'FS' = SINGLE POINT FUSING

Pg 2 of 2