

**INSTALLER CHECK APPROPRIATE BOX AND PLACE LABEL ON OUTSIDE ACCESS PANEL**

<b>MODEL NO:</b> WKF0802	<b>VOLTS:</b>	208 1P	230 1P
<b>TAG:</b> EHK07AKN1 / EHK07AKN	<b>HTR WATTS:</b>	6000	7360
page 1 of 2	<b>HTR AMPS:</b>	28.8	32.0

<b>EQUIPMENT MODEL NO</b>	<b>MCA</b>	<b>MOCP</b>	<b>MCA</b>	<b>MOCP</b>
EBP1800A-6000A, FXM4X 18-60	44.5	45	48.5	50
EBP1800B-6000B, WAP(M,T) 18-60	44.5	45	48.5	50
EBX2400A-6000A	44.5	45	48.5	50
EBV2400A-6000A	44.5	45	48.5	50
FEM, FSM, FSU,FVM (2,4) 1800A-6000A	44.5	45	48.5	50
WAH(M,T) 18-60, FCM4X 24-60	44.5	45	48.5	50

