

**INSTALLER CHECK APPROPRIATE BOX AND PLACE LABEL ON OUTSIDE ACCESS PANEL**

<b>MODEL NO:</b> WKF2005A	<b>VOLTS:</b>	480-3P
	<b>HTR WATTS:</b>	20000
	<b>HTR AMPS:</b>	24.1

<b>EQUIPMENT MODEL NO</b>	<b>MCA</b>	<b>MOCP</b>
EBP3600A-6000A, WAP(M,T) 36-60	33.9	35
EBP3600B-6000B, FCM4X 36-60	33.9	35
EBX3600A-6000A	33.9	35
EBV3600A-6000A	33.9	35
FXM4X 3000A-6000A	33.9	35
FEM\FSM\FSU 3000A-6000A	33.8	35

