

**INSTALLER CHECK APPROPRIATE BOX AND PLACE LABEL ON OUTSIDE ACCESS PANEL**

<b>MODEL NO:</b> WKF0305A	<b>VOLTS:</b>		480-3P
	<b>HTR WATTS:</b>		3000
<b>SINGLE POINT</b>	<b>HTR AMPS:</b>		3.6
<b>EQUIPMENT MODEL NO</b>	<b>MCA</b>	<b>MOCP</b>	<b>MCA</b> <b>MOCP</b>
FV4C,FV4B,FE4A,FE5A,40FKA,FV4A 002-006			8.8   15
FA4B,FB4B,FC4C 018-070			7.8   15
PF1MN,PF4MN 018-061			8.3   15
FX4C,FC4D 018-060			8.3   15
FK4D,FK4C 001-006			8.8   15
FY4A,FA4C,FX4B 018-060			7.8   15
FA4A,FB4A,FC4B 018-070			7.9   15
FH4A 001-004			7.9   15
FX4A 030-060			7.8   15
FX4D 019-061			8.3   15

