

**INSTALLER CHECK APPROPRIATE BOX AND PLACE LABEL ON OUTSIDE ACCESS PANEL**

<b>MODEL NO:</b> WKF0502	<b>VOLTS:</b>	208-1P	230-1P	
<b>TAG:</b> CE/KFCEH0501N05	<b>HTR WATTS:</b>	3750	4600	
CE0501N05	<b>HTR AMPS:</b>	18.0	20.0	
<b>EQUIPMENT MODEL NO</b>	<b>MCA</b>	<b>MOCP</b>	<b>MCA</b>	<b>MOCP</b>
FY4A,FA4C,FX4C,FX4D,FC4D,	26.0	30	28.4	30
PF1M,PF4M,FB4C,FY5B 018-037 / FZ4A 024-036				
FY4A,FA4C,FX4C,FX4D,FC4D,	31.2	35	33.5	35
PF1M,PF4M,FB4C,FY5B 042-061 / FZ4A 048-061				
FK4D,FV4B, FV4C, FE4A,FE5A 002-006	31.2	35	33.5	35

