

**INSTALLER CHECK APPROPRIATE BOX AND PLACE LABEL ON OUTSIDE ACCESS PANEL**

<b>MODEL NO:</b> WKF1202B	<b>VOLTS:</b>	208-1P	230-1P	
	<b>HTR WATTS:</b>	9000	11040	
	<b>HTR AMPS:</b>	28.8-14.4	32.0-16.0	
<b>EQUIPMENT MODEL NO</b>	<b>MCA</b>	<b>MOCP</b>	<b>MCA</b>	<b>MOCP</b>
FV4C,FV4B,FE4A,FE5A,40FKA,FV4A 002-006	44.5-18.0	45-20	48.5-20.0	50-20
FA4B,FB4B,FC4C 024-070	42.5-18.0	45-20	46.5-20.0	50-20
PF1MN,PF4MN 024-061	43.5-18.0	45-20	47.5-20.0	50-20
FX4C,FX4D,FC4D,FB4C,FY5B 024-060	43.5-18.0	45-20	48.5-20.0	50-20
FK4D,FK4C 001-006	44.5-18.0	45-20	48.5-20.0	50-20
FY4A,FA4C 024-060	42.5-18.0	45-20	46.5-20.0	50-20
FA4A,FB4A,FC4B 024-070	44.5-18.0	45-20	46.5-20.0	50-20
FH4A,FH4B,FH4C 001-004	42.8-18.0	45-20	46.8-20.0	50-20
FX4A,FX4B 030-060	42.5-18.0	45-20	46.5-20.0	50-20

