

**INSTALLER CHECK APPROPRIATE BOX AND PLACE LABEL ON OUTSIDE ACCESS PANEL**

<b>MODEL NO:</b> WKF1502(B)	<b>VOLTS:</b>	208 1P	230 1P
<b>TAG:</b> EHK15AKF(B) / EHC15AKF(B)	<b>HTR WATTS:</b>	11250	13800
page 1 of 2	<b>HTR AMPS:</b>	36.1-18.0	40.0-20.0

<b>EQUIPMENT MODEL NO</b>	<b>MCA</b>	<b>MOCP</b>	<b>MCA</b>	<b>MOCP</b>
DUAL POINT				
EBP,X,V/FEM,FSU,FSM,FVM 2,4- 2400-6000A,B	53.6-22.5	60-25	58.5-25	60-25
WAH(M,T) 24-60, FXM4X 24-60, FC(X)M4X 24-60	53.6-22.5	60-25	58.5-25	60-25
SINGLE POINT				
EBP,X,V/FEM,FSU,FSM,FVM 2,4-2400-6000A,B	76.1	80	83.5	90
WAH(M,T) 24-60, FXM4X 24-60, FC(X)M4X 24-60	76.1	80	83.5	90