

**INSTALLER CHECK APPROPRIATE BOX AND PLACE LABEL ON OUTSIDE ACCESS PANEL**

<b>MODEL NO:</b> WKF1502FS	<b>VOLTS:</b>	208 1P	230 1P
	<b>HTR WATTS:</b>	11250	13800
	<b>HTR AMPS:</b>	36.1-18.0	40.0-20.0

<b>EQUIPMENT MODEL NO</b>	<b>MCA</b>	<b>MOCP</b>	<b>MCA</b>	<b>MOCP</b>
SINGLE POINT				
EBP, X, V/FEM, FSU, FSM, FVM 2, 4-2400-6000A, B	76.1	80	83.5	90
WAH(M,t) 24-60, FXM4X 24-60, FCM4X 24-60	76.1	80	83.5	90
WAP(M,T), FXM4X 24-60	75.1	80	82.5	90

