

**INSTALLER CHECK APPROPRIATE BOX AND PLACE LABEL ON OUTSIDE ACCESS PANEL**

<b>MODEL NO:</b> WKF1504B	<b>VOLTS:</b>	208-3P	240-3P
	<b>HTR WATTS:</b>	11250	13800
	<b>HTR AMPS:</b>	31.2	39.6

<b>EQUIPMENT MODEL NO</b>	<b>MCA</b>	<b>MOCP</b>	<b>MCA</b>	<b>MOCP</b>
EBP3600A-6000A, WAP(M,T) 36-60	47.7	50	51.8	60
EBP3600B-6000B, FXM4X 24-60	47.7	50	51.8	60
EBX3600A-6000A, WAHL 364,424,484,604	47.7	50	51.8	60
EBV3600A-6000A	47.7	50	51.8	60
FEM 3500-6000	47.7	50	51.8	60
FSU,FSM 3500-4850, FCM4X 24-60	47.7	50	51.8	60

