

**INSTALLER CHECK APPROPRIATE BOX AND PLACE LABEL ON OUTSIDE ACCESS PANEL**

<b>MODEL NO:</b> WRX0302(B/X)	<b>VOLTS:</b>	208-1P	240-1P
<b>TAG:</b> RXBH17(24)A-03J	<b>HTR WATTS:</b>	2250	3000
	<b>HTR AMPS:</b>	10.8	12.5

<b>EQUIPMENT MODEL NO</b>	<b>MCA</b>	<b>MOCP</b>	<b>MCA</b>	<b>MOCP</b>
UHLA/SA/LL/SL 18-36(17,21,24)	18.6	20	20.8	25
RHLA/SA/LL/SL 18-36(17,21,24)	16.6	20	18.3	20
RHKA/RHKL 18-36(17), RHPL 36(21)	18	20	20	20
RHKA/ RHKL 42-60(21,24)	22	25	25	25
RHPN 24(21), RHPL 24(21)	16	20	18	20
RHPN 36(24), RHPL 48-60(24)	20	20	22	25
RHMV 2417SEAC	17	20	19	20
RHMV 3617SEAC	18	20	20	20

