

INSTALLER CHECK APPROPRIATE BOX AND PLACE LABEL ON OUTSIDE ACCESS PANEL

| | | | |
|---|-------------------|--------|--------|
| MODEL NO: WRX0502(B/X) | VOLTS: | 208-1P | 240-1P |
| TAG: RXBH17(24)A-05J/ RXBH1724A(B)-05J | HTR WATTS: | 3600 | 4800 |
| PAGE 3 OF 3 | HTR AMPS: | 17.3 | 20.0 |

| EQUIPMENT MODEL NO | MCA | MOCP | MCA | MOCP |
|----------------------------|------------|-------------|------------|-------------|
| RHMV 2417SEAC | 25 | 25 | 29 | 30 |
| RHMV 2421HEAC | 27 | 30 | 31 | 35 |
| RHMV 2421MEAC | 24 | 25 | 28 | 30 |
| RHMV 3617SEAC | 26 | 30 | 30 | 30 |
| RHMV 6021SEAC | 28 | 30 | 32 | 35 |
| FH 2417 TTS | 26 | 30 | 29 | 30 |
| FH 3617,3621,4821,6021 TTS | 27 | 30 | 31 | 35 |
| FH 4824,6024 TTS | 30 | 30 | 33 | 35 |
| FH 1817,2417 TPS | 22 | 25 | 28 | 30 |
| FH 3017,3617,3621 TPS | 25 | 25 | 30 | 30 |
| FH 4221,4821,4824,6024 TPS | 29 | 30 | 32 | 35 |
| | | | | |
| | | | | |
| | | | | |

