

**INSTALLER CHECK APPROPRIATE BOX AND PLACE LABEL ON OUTSIDE ACCESS PANEL**

<b>MODEL NO:</b> WRX2002S(B/X)	<b>VOLTS:</b>	208-1P	240-1P
<b>TAG:</b> RXBH17, 24A-20J	<b>HTR WATTS:</b>	14400	19200
PAGE 2 OF 2	<b>HTR AMPS:</b>	69.2	80.0

<b>EQUIPMENT MODEL NO</b>	<b>MCA</b>	<b>MOCP</b>	<b>MCA</b>	<b>MOCP</b>
SINGLE CIRCUIT				
RHMV 2421HEAC / RH1(2)T 4824,6024 ST(MT)	92	100	106	110
RHMV 6021SEAC / RH2V 4824,6024 HT	93	100	107	110
RH1P 4221,4821,4824,6024 ST	93	100	107	110
RH1V 3621HT,3621HT,4821MT,4821 ST	92	100	106	110
RH1V 4824,6024 ST	95	100	109	110
DUAL CIRCUIT				
RHMV 2421HEAC / RH1(2)T 4824,6024 ST(MT)	49-44	50-45	56-50	60-50
RHMV 6021SEAC / RH2V 4824,6024 HT	50-44	50-45	57-50	60-50
RH1P 4221,4821,4824,6024 ST	50-44	50-45	57-50	60-50
RH1V 3621HT,3621HT,4821MT,4821 ST	49-44	50-45	56-50	60-50
RH1V 4824,6024 ST	52-44	60-45	59-50	60-50
RV042718				

