

**INSTALLER CHECK APPROPRIATE BOX AND PLACE LABEL ON OUTSIDE ACCESS PANEL**

<b>MODEL NO:</b> WGM0502	<b>VOLTS:</b>	208-1P	240-1P
<b>TAG:</b> BAYEAC05LG1A	<b>HTR WATTS:</b>	3600	4800
* = A, T page 1 of 2	<b>HTR AMPS:</b>	17.3	20.0

<b>EQUIPMENT MODEL NO</b>	<b>MCA</b>	<b>MOCP</b>	<b>MCA</b>	<b>MOCP</b>
GAM5A(B)0 A18, A24, B30	25	25	29	30
GAM5A(B)0 B36, C42	27	30	30	30
GAM5A(B)0 C48	29	30	33	35
GAM5A(B)0 C60	31	35	35	35
*AM4AO A18, A24, A30, A36, B42	25	25	28	30
*AM4AO C48	26	30	29	30
*AM4AO C60	31	35	35	35
GAT2AO, GAM2AO B42	25	25	28	30
GAT2AO, GAM2AO C48	26	30	29	30
GAT2AO, GAM2AO C60	31	35	35	35
GAM2AO A18	24	25	28	30
GAM2AO A24	23	25	27	30
GAM2AO A30	24	25	27	30
GAM2AO A36	25	25	28	30

